

## **Certificate of Analysis**

## For Research Use Only Not for Human or Animal Consumption

## **KPL SureBlue**<sup>™</sup> **TMB Microwell Peroxidase Substrate (1-Component)**

**PART CODE:** 5120-0077 (52-00-03)

**LOT NUMBER:** 10502759 **SIZE** 1000 mL

**DESCRIPTION:** This liquid substrate system develops a dark blue soluble product when reacted with horseradish

peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane

or immunohistochemical staining assays.

**FORM/STORAGE:** Liquid. Store refrigerated at 2 - 8°C.

**CONTENT:** The one component system is supplied as 1000 mL bottles, from bulk Lot No. 10502759. The

KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains

3,3',5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide

is 0.01%.

**STABILITY:** Product is stable for three years from date of manufacture when stored properly.

**DATE OF** 

MANUFACTURE: 08 JUL 2020

RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product:

- Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful.
- Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container.
- Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents.
  - Do not refilter as this may destabilize the dye complex and result in the development of background color.
- Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance.
- HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended.
- Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon.
- Gravity fill or the use of a peristaltic pump is advised.
- · Avoid substrate contact with any metallic surfaces.
- For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.

Approval:

22 JUL 2020

QA Verified By Date

910 Clopper Road, Gaithersburg, MD 20878 • 508.244.6400 • 800.676.1881 Toll Free • 508.634.3334 Fax www.seracare.com